



Unit 11 Vale Park
Colomendy Industrial Estate
Denbigh, North Wales, LL16 5TD
Tel No: + 44 (0) 1745 815 222
Fax No: + 44 (0) 1745 815 333
www.steammodels.com
e-mail mss@steammodels.co

Parts List

4-Side Frames (Black)
4-Drag Beams (Black)
2-Wagon Floor

4-Axle assy

FLAT BED WAGON KIT

Bag 1

8- Buffer Stock (Black)
4- Coupling Links
8- Buffers (Brass)
8- Brass 6BA Nuts

Bag 2

8 - 2.5 x 6 mm Black screws
8 - 2.5 x 6BA Black nuts
4 - Buffer Beams (Red)

You will also require a small screwdriver, spanner for the 6BA nuts and a small pair of pliers. Check that all parts are present and proceed.

Assembly Instructions

1. Fit the red buffer beams on to the drag beam by sliding them over the coupling link brackets. Fit the coupling links by clipping them through the complete slot in the brackets.
2. Take one side frame and fit a drag beam to each end using 2 buffers with buffer stock fitted, the large diameter of the buffer stock against the buffer beam and 2 x 6 BA nuts. The closed part of the drag beam goes to the top.
3. Mount the 2 wheel and axle assemblies into the holes in the wheel bearings on the side frame that you have already fitted. Attach the second side frame in the same way as the first.
4. Using the 4 x 2.5 mm screws and nuts, screw the wagon floor on to the chassis, inserting the screws from the top..
5. Make sure all the nuts are tight, put a spot of oil on to each axle bearing, and the FLAT BED WAGON is complete.

