The Summerlands Chuffer

General Purpose 3/16" single exhaust SCGP3

Thank you for buying the Summerlands Chuffer – it has been developed by enthusiasts to bring the magic of a good chuff to your steam loco. Please take a moment to read the following points before fitting the Chuffer to your loco.

- This version of the Summerlands Chuffer has been developed for fitting to locos which
 have a single, 3/16" outside diameter exhaust. Fitting will inevitably involve some
 dismantling of your loco and cutting the exhaust to the correct length. If, having read the
 instructions below, you are in any doubt about your ability to fit the Chuffer, please seek
 advice from someone with model engineering skills. We cannot accept responsibility for any
 damage caused by incorrect fitting.
- If your loco is still under guarantee, then simply replacing the exhaust should not affect that guarantee. However, any damage done during fitting will not be covered and if you are in any doubt, please contact your retailer or the manufacturer.
- Your Summerlands Chuffer will be much louder and clearer than with the factory exhaust.
 However, just like on full sized locos, the volume will also depend how hard the loco is working due to gradient or load. Work it hard for the best chuff!
- If you decide that this product is not for you then send it back to us undamaged, within 56 days of purchase to the address below, together with your receipt (or details of where purchased) and name and address, for a full refund of the purchase price (excluding any additional post and packing).

Fitting the Chuffer

Because this *Chuffer* is designed to fit a wide range of locos, it is impossible to give instructions so these are simply guidlines:

- For the Chuffer to function correctly on an internally fired loco, the chimney must ideally
 have a minimum internal diameter of 9.5mm and an internal length of 47mm. This will
 ensure free gas flow round the Chuffer and ensure that the Chuffer can operate correctly.
- When setting the position of the Chuffer, ensure that the entire sounding slot is inside the
 chimney this may mean that the top of the Chuffer is within a millimetre or so of the top of
 the chimney. If there is plenty of chimney length, then ensure that the entire Chuffer is
 inside the chimney.
- 3. If it is necessary to cut your exhaust, then ensure it is firmly supported.
- 4. When fitted, ensure that the *Chuffer's* sounding slot is clear of the chimney wall so that it is not muffled. The top of the *Chuffer* is marked with a line to show the position of the slot.
- 5. The 7/32" brass tube fitted to the *Chuffer* may be shortened by carefully cutting with a fine hacksaw or cutting disc (always wear appropriate eye protection if using the latter). Please remember that the brass will be soft and must be properly supported for cutting.
- 6. This tube is a nice push fit on to the 3/16" exhaust but to ensure a good fit, allow 20mm or more of overlap unless silver soldering. If it is loose, then a slight bend in the copper exhaust pipe will hold it firm.
- 7. The top of the Chuffer can be disguised with a little matt black paint.
- 8. And finally remember that slow running and a good load gives the best chuff!

Nigel Garrett **DP Supplies** Unit 19 Jubilee Enterprise Centre, Jubilee Close, Weymouth, Dorset, DT4 7BS 01305 781911 enquiries@dp-supplies.co.uk

Please check out our website for the latest *Chuffer* news, information and videos www.summerlands-chuffer.co.uk